Mandis shop

RM-14-A

Original		Replacement		Original		Replacement	
	Power	ON	On				
	Power	OFF	OFF				
	Vol -	VOL PAGE —	Vol -				
	Vol -	K.S. ZOOM	KS Down				
	Point	1 POINT	1 / Point				
	Vol +	+ VOL PAGE	Vol +				
	Vol +	K.S. ZOOM	KS Up				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
OK	OK	OK	OK				
	Back	EXIT/LAMP	Exit / Lamp				
	Menu	MENU/INFO	Menu / Info				
	3D	3	3				
	Home	MODE AUTO	Auto / Mode				
	Settings	ASPECT/RE	Aspect / Re-Sync				