Original		Replacement	
	Standby		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Vol +		Vol +
	Vol -		Vol -
	Left		Left
	Right		Right
	I <<		I << / Preset -
	>>I		>>I / Preset +

Original		Replacement	
	Stop		Stop / Hold
	Play/Pause		Play / Slow
	Play/Pause		Pause / Step / Freeze
	I >/ Resume		Shift + Play /
	Surround		Eject / Surround
	Sound		Sound / Title
	Night		Shift + Sleep / Timer
	Mute		Mute / Dimmer
	Repeat		Green / APP / Repeat
	Repeat A-B		Yellow / YouTube / Repeat
	Sleep		Sleep / Timer
	DIM		Shift + Mute / Dimmer
	Subw +		Up
	Rear +		Shift + CH+ /
	Center +		CH+ / Page+
	Tv Vol +		Shift + Vol +
	Subw -		Down

Original	Replacement	Original	Replacement
REAR Rear -	SHIFT + CH PAGE Shift + CH- /		
CENTER Center -	CH PAGE CH- / Page-		
TV VOL Tv Vol -	SHIFT + VOL Shift + Vol -		

Original		Replacement	
	Standby		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Disc (DVD		D. Menu / Top
	0		0
	Vol +		Vol +
	System (DVD		Menu / Home
	Vol -		Vol -
	I <<		I << / Preset -
	>>I		>>I / Preset +

Original		Replacement	
	Stop		Stop / Hold
	Play/Pause		Play / Slow
	I >/ Resume		Shift + Play /

Original	Replacement	Original	Replacement
Standby	Power		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Up	Up		
Left	Left		
OK	OK		
Right	Right		
Down	Down		

Original		Replacement		Original	Replacement
	St andby		Power		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		