Mandis shop

EUR646550

Original	Replacement
A1	1
A2	2
Off	Power
I<< CD	I<< / Preset-
>>I CD	>>I / Preset+
Play CD	Play / Slow
Pause CD	Pause / Step / Freeze
Stop/Clear CD	Stop / Hold
CD Play Mode	3
Band	Sound / Title
Preset Tune Down	Down
Preset Tune Up	Up
Tune-	<< / Tune-
Tune+	>> / Tune+
XBS	Display / Media
S.Virtualizer	Smart / List
Sleep	Sleep / Timer

Original	Replacement
Volume-	Vol -
Volume+	Vol +

https://remotes.com/Panasonic/EUR646550-replacement-remote-for-Panasonic-EUR646550.htm