Original		Replacement	
CD	CD	SHIFT + CD-STB 3	Shift + 3
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TXT	TXT	GOTO TEXT	Text / Goto
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
TV	TV	SHIFT + TV 1	Shift + 1
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO	Volume Audio +	+ VOL	Vol+
VOLUME AUDIO	Volume Audio -	VOL −	Vol-
VOLUME TV −	Volume TV -	◀	Left
VOLUME TV +	Volume TV +	▶	Right
AUDIO PROC −	Audio Processor -	▼	Down
PROCESSOR +	Audio Processor +	▲	Up

Original		Replacement	
TV	TV -/--	-/-- GUIDE EPG	Guide / EPG / -/--
1	TV 1	TV 1	1
2	TV 2	DVD 2	2
3	TV 3	CD-STB 3	3
4	TV 4	VIDEO 4	4
5	TV 5	TAPE 5	5
6	TV 6	TUNER 6	6
7	TV 7	AUX-HDD 7	7
8	TV 8	USB 8	8
9	TV 9	BLUETOOTH 9	9
0	TV 0	HDMI-SAT 0	0
MUTE	TV Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK	TV Preset +	PRESET+ ▶▶I	>>I / Preset+
PRESET TRACK	TV Preset -	PRESET- I◀◀	I<< / Preset-
STANDBY	TV Standby	⏻	Power
HOLD STOP	TV-TXT Hold	HOLD ■	Stop / Hold
MEMO OUT PLAY	TV-TXT Memo	REC MODE ●	Rec / Rec Mode

Original		Replacement	
REVEAL ◀◀	TV-TXT Reveal	SLOW ▶	Play / Slow
CANCEL PAUSE	TV-TXT Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIME ▶▶	TV-TXT Time	TIMER SLEEP	Sleep / Timer
ENLARGE MODE	TXT Enlarge	SIZE ZOOM	Zoom / Size
ENLARGE MODE	TV Mode	OK	OK
PRESET TRACK	TXT Preset +	+ CH PAGE	CH+ / Page+
PRESET TRACK	TXT Preset -	CH PAGE −	CH- / Page-
STANDBY	DCC Standby	SHIFT + ⏻	Shift + Power
MUTE	DCC Mute	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
DECK A DISC	DCC Disc +	SHIFT + + CH PAGE	Shift + CH+ /
DISC DECK B	DCC Disc -	SHIFT + CH PAGE −	Shift + CH- /
PRESET TRACK	DCC Track +	SHIFT + PRESET+ ⏭	Shift + >>I / Preset+
PRESET TRACK	DCC Track -	SHIFT + PRESET- ⏮	Shift + I<< / Preset-
HOLD STOP	DCC Stop	SHIFT + HOLD ■	Shift + Stop /
MEMO OUT PLAY	DCC Play	SHIFT + SLOW ▶	Shift + Play /
REVEAL ◀◀	DCC <<	SHIFT + TUNE- ◀◀	Shift + << /
CANCEL PAUSE	DCC Pause	SHIFT + STEP-FREEZE ⏸	Shift + Pause / Step / Freeze

Original		Replacement	
TIME ▶▶	DCC >>	SHIFT + TUNE+ ▶▶	Shift + >> /
ENLARGE MODE	DCC Mode	SHIFT + OK	Shift + OK
OPEN/CLOSE	DCC	SHIFT + SURROUND ⏏	Shift + Eject / Surround

Original		Replacement	
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD - STB 3	Shift + 3
TXT	TXT	GOTO TEXT	Text / Goto
TV	TV	SHIFT + TV 1	Shift + 1
DSR	DSR	SHIFT + AUX - HDD 7	Shift + 7
DCC	DCC	SHIFT + DVD 2	Shift + 2
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO	Volume Audio +	+ VOL	Vol+
VOLUME AUDIO	Volume Audio -	VOL −	Vol-
PROCESSOR +	Audio Processor +	▲	Up
AUDIO PROC −	Audio Processor -	▼	Down
VOLUME TV +	Volume TV +	▶	Right
VOLUME TV −	Volume TV -	◀	Left

Original		Replacement	
STANDBY	CD Standby	⏻	Power
1	CD 1	TV 1	1
2	CD 2	DVD 2	2
3	CD 3	CD - STB 3	3
4	CD 4	VIDEO 4	4
5	CD 5	TAPE 5	5
6	CD 6	TUNER 6	6
7	CD 7	AUX - HDD 7	7
8	CD 8	USB 8	8
9	CD 9	BLUETOOTH 9	9
0	CD 0	HDMI - SAT 0	0
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DECK A DISC	CD Disc +	+ CH PAGE	CH+ / Page+
DISC DECK B	CD Disc -	CH PAGE −	CH- / Page-
PRESET TRACK	CD Track +	PRESET+ ⏭	>>I / Preset+
PRESET TRACK	CD Track -	PRESET- ⏮	I<< / Preset-
HOLD STOP	CD Stop	HOLD ■	Stop / Hold

Original	Replacement
CD Play	Play / Slow
CD <<	<< / Tune-
CD Pause	Pause / Step / Freeze
CD >>	>> / Tune+
CD Mode	OK
CD Open/Close	Eject / Surround
DSR Standby	Shift + Power
DSR Disc +	Shift + CH+ /
DSR Disc -	Shift + CH- /
DSR Preset/Track	Shift + >>I / Preset+
DSR Preset/Track	Shift + I<< / Preset-
DSR Mode	Shift + OK

Original	Replacement

Original		Replacement	
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD - STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX - HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
TXT	TXT	GOTO TEXT	Text / Goto
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO	Volume Audio +	+ VOL	Vol+
VOLUME AUDIO	Volume Audio -	VOL −	Vol-
VOLUME TV	Volume TV -	◀	Left
VOLUME TV +	Volume TV +	▶	Right
AUDIO PROC −	Audio Processor -	▼	Down
PROCESSOR +	Audio Processor +	▲	Up

Original		Replacement	
1	TUNER 1	TV 1	1
2	TUNER 2	DVD 2	2
3	TUNER 3	CD - STB 3	3
4	TUNER 4	VIDEO 4	4
5	TUNER 5	TAPE 5	5
6	TUNER 6	TUNER 6	6
7	TUNER 7	AUX - HDD 7	7
8	TUNER 8	USB 8	8
9	TUNER 9	BLUETOOTH 9	9
0	TUNER 0	HDMI - SAT 0	0
STANDBY	TUNER Standby	⏻	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK	TUNER Preset +	PRESET+ ▶▶I	>>I / Preset+
PRESET TRACK	TUNER Preset -	PRESET- I◀◀	I<< / Preset-
REVEAL ◀◀	TUNER <<	TUNE- ◀◀	<< / Tune-
TIME ▶▶	TUNER >>	TUNE+ ▶▶	>> / Tune+
ENLARGE MODE	TUNER Mode	OK	OK

Original	Replacement	Original	Replacement
STANDBY TAPE Standby	SHIFT + Power		
PRESET TRACK TAPE Preset +	SHIFT + PRESET+ Shift + >>I / Preset+		
DECK A DISC TAPE Deck A	SHIFT + LIST SMART Shift + Smart / List		
PRESET TRACK TAPE Preset -	SHIFT + PRESET- Shift + I<< / Preset-		
DISC DECK B TAPE Deck B	SHIFT + MEDIA DISPLAY Shift + Display / Media		
HOLD STOP TAPE Stop	SHIFT + HOLD Shift + Stop /		
MEMO OUT PLAY TAPE Play	SHIFT + SLOW Shift + Play /		
REVEAL TAPE <<	SHIFT + TUNE- Shift + << /		
TIME TAPE >>	SHIFT + TUNE+ Shift + >> /		
ENLARGE MODE TAPE Mode	SHIFT + OK Shift + OK		
RECORD TAPE Record	SHIFT + REC MODE Shift + Rec / Rec Mode		
CANCEL PAUSE TAPE Pause	SHIFT + STEP - FREEZE Shift + Pause / Step /		
OPEN/CLOSE TAPE	SHIFT + SURROUND Shift + Eject / Surround		

Original		Replacement	
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TXT	TXT	GOTO TEXT	Text / Goto
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD - STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX - HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO	Volume Audio +	+ VOL	Vol+
VOLUME AUDIO	Volume Audio -	VOL −	Vol-
VOLUME TV	Volume TV -	◀	Left
VOLUME TV	Volume TV +	▶	Right
AUDIO PROC −	Audio Processor -	▼	Down
PROCESSOR +	Audio Processor +	▲	Up

Original		Replacement	
1	VCR 1	TV 1	1
2	VCR 2	DVD 2	2
3	VCR 3	CD - STB 3	3
4	VCR 4	VIDEO 4	4
5	VCR 5	TAPE 5	5
6	VCR 6	TUNER 6	6
STANDBY	VCR Standby	⏻	Power
7	VCR 7	AUX - HDD 7	7
8	VCR 8	USB 8	8
9	VCR 9	BLUETOOTH 9	9
0	VCR 0	HDMI - SAT 0	0
VCR	VCR -/--	-/-- GUIDE EPG	Guide / EPG / -/--
MUTE	VCR Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK	VCR Preset/Track	PRESET+ ⏭	>>I / Preset+
PRESET TRACK	VCR Preset/Track	PRESET- ⏮	I<< / Preset-
HOLD STOP	VCR Stop	HOLD ■	Stop / Hold
MEMO OUT PLAY	VCR Play	SLOW ▶	Play / Slow

Original	Replacement	Original	Replacement
REVEAL ◀◀ VCR <<	TUNE- ◀◀ << / Tune-		
CANCEL PAUSE VCR Pause	STEP-FREEZE ❚❚ Pause / Step / Freeze		
TIME ▶▶ VCR >>	TUNE+ ▶▶ >> / Tune+		
RECORD VCR Record	REC MODE ● Rec / Rec Mode		
ENLARGE MODE VCR Mode	OK OK		
OPEN/CLOSE VCR Open/Close	SURROUND ⏏ Eject / Surround		
STANDBY DIG.REC	SHIFT + ⏻ Shift + Power		
MUTE DIG.REC Mute	SHIFT + DIMMER MUTE Shift + Mute / Dimmer		
PRESET TRACK DIG.REC Preset/Track +	SHIFT + PRESET+ ▶▶I Shift + >>I / Preset+		
PRESET TRACK DIG.REC Preset/Track -	SHIFT + PRESET- I◀◀ Shift + I<< / Preset-		
HOLD STOP DIG.REC Stop	SHIFT + HOLD ■ Shift + Stop /		
CANCEL PAUSE DIG.REC Pause	SHIFT + STEP-FREEZE ❚❚ Shift + Pause / Step /		
REVEAL ◀◀ DIG.REC <<	SHIFT + TUNE- ◀◀ Shift + << /		
TIME ▶▶ DIG.REC >>	SHIFT + TUNE+ ▶▶ Shift + >> /		
ENLARGE MODE DIG.REC Mode	SHIFT + OK Shift + OK		
MEMO OUT PLAY DIG.REC Play	SHIFT + SLOW ▶ Shift + Play /		
OPEN/CLOSE DIG.REC Open/Close	SHIFT + SURROUND ⏏ Shift + Eject / Surround		