Original	Replacement	Original	Replacement
TV Direct	Smart / List	Dimmer	Shift + Mute / Dimmer
Power DVD	Red / Netflix / Search	Sleep	Sleep / Timer
Power VCR	Green / APP / Repeat	Analog/Digital Input	AV / Input / RDS
Power Audio	Power	Smart S Setup	Setup / OPT /
Power STB	Yellow / YouTube / Repeat	Bass Boost	Audio / Lang I/II
Power TV	Blue / Prime Video / Random	C. Tone	Subtitle / EQ
DVD	2	A. Position	D. Menu / Top
VCR	4	Test Tone	Text / Goto
TV	1	Effect	Info / Angle
FM/AM	6	Decode	TV/Radio /
Tv/Video	5	Surround	Eject / Surround
Muting	Mute / Dimmer	Subwfr+	Right
Channel +	CH+ / Page+	Center+	Up
Volume+	Vol +	Surr L+	Shift + Vol +
Channel -	CH- / Page-	Surr R+	Shift + CH+ /
Volume-	Vol -	Subwfr-	Left
Display/On Screen	Display / Media	Center-	Down

Original	Replacement	Original	Replacement
Surr L-	SHIFT + VOL − Shift + Vol -		
Surr R-	SHIFT + CH PAGE − Shift + CH- /		

Original	Replacement	Original	Replacement
Power Audio	Power	Display FM/AM	Display / Media
Power Tv	Shift + Power	1 FM/AM	Shift + 1
FM/AM	Eject / Surround	1 TV	1
Tv Vol +	Vol +	2 FM/AM	Shift + 2
Channel + TV	CH+ / Page+	2 TV	2
Tv Vol -	Vol -	3 FM/AM	Shift + 3
Channel - TV	CH- / Page-	3 TV	3
Tuning- FM/AM	<< / Tune-	4 FM/AM	Shift + 4
FM Mode FM/AM	Smart / List	4 TV	4
Tuning+ FM/AM	>> / Tune+	5 FM/AM	Shift + 5
Memory FM/AM	Menu / Home	5 TV	5
TA/News/Info	Info / Angle	6 FM/AM	Shift + 6
TA/News/Info	Up	6 TV	6
PTY- FM/AM	Left	7 FM/AM	Shift + 7
PTY+ FM/AM	Right	7 TV	7
PTY Search	Down	8 FM/AM	Shift + 8
PTY Search	Red / Netflix / Search	8 TV	8

FM/AM

Original		Replacement		Original	Replacement
9	9 FM/AM	SHIFT + BLUETOOTH 9	Shift + 9		
9	9 TV	BLUETOOTH 9	9		
TV RETURN 10	10 FM/AM	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC		
TV RETURN 10	10/Tv Return TV	SHIFT + HDMI - SAT 0	Shift + 0		
0	0 TV	HDMI - SAT 0	0		
100+ +10	+10/100+	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		
100+ +10	+10 TV	PC FAV MARKER	Fav / Marker / PC		

Original		Replacement	
Power DVD		Power	
I<<		I<< / Preset-	
Play		Play / Slow	
>>I		>>I / Preset+	
<<		<< / Tune-	
Stop		Stop / Hold	
Pause		Pause / Step / Freeze	
Top Menu		D.Menu / Top	
>>		>> / Tune+	
Up		Up	
Menu		Menu / Home	
Left		SHIFT +	Shift + Left
Enter		OK	
Right		Right	
Set Up		Setup / OPT /	
Down		Down	
On Screen		SHIFT +	Shift + Display / Media

Original		Replacement	
Audio		Audio / Lang I/II	
Subtitle		Subtitle / EQ	
Title Group		SHIFT +	Shift + Sound / Title
Return		Back / Return	
DVD Zoom		Zoom / Size	
1		1	
2		2	
3		3	
VFP Progressiv		Smart / List	
4		4	
5		5	
6		6	
←		Left	
7		7	
8		8	
9		9	
Angle		Info / Angle	

Original		Replacement		Original	Replacement
TV RETURN 10	10	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
100+ +10	+10	PC FAV MARKER	Fav / Marker / PC		
DIMMER	Display/Dimmer	MEDIA DISPLAY	Display / Media		
ANALOG/DIGITAL INPUT	Input Analog/Digital	RDS AV INPUT	AV / Input / RDS		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
EFFECT	HDD Sound Effect	TITLE SOUND	Sound / Title		
SURROUND	Surround	SURROUND ⏏	Eject / Surround		

Original		Replacement	
Power VCR		SHIFT +	Shift + Power
Power STB			Power
VCR		SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
Muting		DIMMER MUTE	Mute / Dimmer
Channel +		CH PAGE +	CH+ / Page+
Volume+		VOL +	Vol +
Channel -		CH PAGE −	CH- / Page-
Volume-		VOL −	Vol -
Play VCR		SLOW ▶	Play / Slow
<< VCR		TUNE- ◀◀	<< / Tune-
Stop/Memory		HOLD ■	Stop / Hold
Pause VCR		STEP-FREEZE ⏸	Pause / Step / Freeze
>> VCR		TUNE+ ▶▶	>> / Tune+
1 VCR		SHIFT + TV 1	Shift + 1
1 STB		TV 1	1
2 VCR		SHIFT + DVD 2	Shift + 2
2 STB		DVD 2	2

Original		Replacement	
3 VCR		SHIFT + CD-STB 3	Shift + 3
3 STB		CD-STB 3	3
4 VCR		SHIFT + VIDEO 4	Shift + 4
4 STB		VIDEO 4	4
5 VCR		SHIFT + TAPE 5	Shift + 5
5 STB		TAPE 5	5
6 VCR		SHIFT + TUNER 6	Shift + 6
6 STB		TUNER 6	6
7 VCR		SHIFT + AUX-HDD 7	Shift + 7
7 STB		AUX-HDD 7	7
8 VCR		SHIFT + USB 8	Shift + 8
8 STB		USB 8	8
9 VCR		SHIFT + BLUETOOTH 9	Shift + 9
9 STB		BLUETOOTH 9	9
TV RETURN 10	+10 TV	-/-- GUIDE EPG	Guide / EPG / -/--
0 VCR		SHIFT + HDMI-SAT 0	Shift + 0
0 STB		HDMI-SAT 0	0