Original		Replacement	
	Power		Power
	TV / Video	SEARCH TV/R	TV/R
	DVD	HOME SMART	Smart
	VCR	APP MEDIA	Media
	Open / Close	ZOOM	Eject
	1	1	1
	2	2	2
	3	3	3
	4	4	4
	5	5	5
	6	6	6
	7	7	7
	8	8	8
	9	9	9
	0	0	0
	Display	DISPLAY INFO	Info
	Up		Up

Original		Replacement	
	Left		Left
	OK	OK	Ok
	Right		Right
	Down		Down
	Stop		Stop
	Play	PLAY MODE	Play
	Pause / Step		Pause
	<< REW		<<
	>> FWD		>>
	Record	REC MODE	Rec
	Clear	CLEAR EXIT	Exit

Original		Replacement	
	Power		Power
	Open / Close		Eject
	DVD		Smart
	VCR		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Return		Back
	Display		Info
	List / Disc Men		D. Menu

Original		Replacement	
	System Menu		Menu
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	I <		I <<
	>I		>>I
	Stop		Stop
	Play		Play
	Pause / Step		Pause
	<< REW		<<
	>> FWD		>>
	Thumbnail		3D
	Chapter		Format
	Timer		AV
	Record		Rec

Original		Replacement		Original	Replacement
REC MODE	Rec. Mode	D	Blue		
REPEAT	Repeat	REPEAT TEXT	Text		
TITLE	Title	SETTINGS OPT	Options		
AUDIO	Audio	SOUND DUAL	Dual		
ZOOM	Zoom	SHIFT +	ZOOM Shift + Eject		
SEARCH	Search	SEARCH TV/R	TV/R		
MARKER	Marker	FAV PRE-CH	Pre Ch		
D.DUBBING	D. Dubbing	-/-- GUIDE	Guide		
CLEAR	Clear	CLEAR EXIT	Exit		
SHOWVIEW VIDEOPLUS+	Showview / VideoPlus+	AD SUBT	Subt		