Original		Replacement	
POWER	Power	Power	
OSD	OSD	MEDIA DISPLAY	Display / Media
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
N/P	N/P	FORMAT PICTURE	Picture / Format
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RAN	RAN	LIST SMART	Smart / List
L/R	L/R	TOP MENU D.MENU	D.Menu / Top
SLOW	Slow	SHIFT + SLOW	Shift + Play /
RESUME	Resume	SHIFT +	Shift + Right
STEP	Step	SHIFT + STEP-FREEZE	Shift + Pause / Step /
KEY +	Key+	CH PAGE +	CH+ / Page+
RETURN	Return	RETURN BACK	Back / Return
3D	3D	SHIFT + CD-STB 3	Shift + 3
VOL +	Vol +	VOL +	Vol +
KEY -	Key-	CH PAGE -	CH- / Page-
TIME	Time	TIMER SLEEP	Sleep / Timer

Original		Replacement	
PDVD	PDVD	RDS AV INPUT	AV / Input / RDS
VOL -	Vol -	VOL -	Vol -
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
Up			Up
TITLE	Title	TITLE SOUND	Sound / Title
Left			Left
ENTER	Enter	OK	OK
Right			Right
MENU	Menu	HOME MENU	Menu / Home
Down			Down
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Replacement		Original		Replacement	
STOP	Stop	HOLD	Stop / Hold	FWD	>> FWD	TUNE+	>> / Tune+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
PREV	I << Prev	PRESET-	I << / Preset-				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
NEXT	>>I Next	PRESET+	>>I / Preset+				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
REV	<< REV	TUNE-	<< / Tune-				
10/0	10/0	HDMI - SAT 0	0				
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--				
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear				