Mandis shop

Philips RC33140101

Original		Replacement	
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL −	Vol -
PRESET	Preset Up		Up
PRESET	Preset Down		Down
TUNING	Tuning >>I		Right
TUNING	I << Tuning		Left
SHUFFLE	Shuffle	SEARCH TV/R	TV/R
REPEAT	Repeat	REPEAT TEXT	Text
	Play	PLAY MODE	Play
	Pause		Pause
	I <		I <<
	>I		>>I
STOP	Stop		Stop
SEARCH	<< Search		<<
SEARCH	Search >>		>>

Original	Replacement

https://remotecontrols.com/Philips/10205-833-replacement-remote-control-for-Philips-RC3140101-3922833.htm