Original	Replacement	Original	Replacement
Power	Power	Up	Up
PP	Back / Return	P+	CH+ / Page+
Mute	Mute / Dimmer	Left	Left
1	1	M	OK
2	2	M	Menu / Home
3	3	Right	Right
4	4	Down	Down
5	5	P-	CH- / Page-
6	6	Vol -	Vol -
7	7	Vol +	Vol +
8	8	Red/ Sound	Red / Netflix / Search
9	9	Red/ Sound	Sound / Title
P<P	Fav / Marker / PC	Green/ Picture	Green / APP / Repeat
0	0	Green/ Picture	Picture / Format
--	Guide / EPG / -/--	Yellow/ Feature	Yellow / YouTube / Repeat
Info	Info / Angle	Blue/ Install	Blue / Prime Video / Random
I-II	Audio / Lang I/II	TV	Display / Media

Original	Replacement	Original	Replacement
AV	AV / Input / RDS		
[≡]	Text / Goto		
[/ ≡]	<< / Tune-		
[≡o]	Sleep / Timer		
[≡+]	Stop / Hold		
[≡x]	>> / Tune+		
[≡♦]	Zoom / Size		
[≡?]	Pause / Step / Freeze		
[≡i]	Play / Slow		