Original		Replacement	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + 1	Shift + 1
DVD	DVD	SHIFT + 2	Shift + 2
TV AUDIO	Tv Audio	SOUND DUAL	Dual
Blu-ray	Blu-ray	SHIFT + 3	Shift + 3
AUX	AUX	SHIFT + 4	Shift + 4
TUNER	Tuner	SHIFT + 5	Shift + 5
Bluetooth	Bluetooth	SHIFT + 6	Shift + 6
GAME	Game	SHIFT + 7	Shift + 7
8K	8K	SHIFT + 8	Shift + 8
PHONO	Phono	SHIFT + 9	Shift + 9
USB	USB	FAV PRE-CH	Pre Ch
MEDIA PLAYER	Media Player	APP MEDIA	Media
CD	CD	-/-- GUIDE	Guide
	Heos	SHIFT + 0	Shift + 0
INTERNET RADIO	Internet Radio	SEARCH TV/R	TV/R
CH/PAGE	CH/Page+	+ CH	Ch +

Original		Replacement	
	CH/Page-	CH –	Ch -
SLEEP	Sleep	PROG SLEEP	Sleep
ECO	Eco	ECO 3D	3D
VOLUME	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
HOME	Home	HOME SMART	Smart
	Stop		Stop

Original		Replacement	
	Pause		Pause
	Play	PLAY MODE	Play
TUNE	I <</ Tune-		I <<
TUNE +	>>I / Tune+		>>I
	<<		<<
	>>		>>
1	Smart Select 1	E-MANUAL D.MENU	D. Menu
2	Smart Select 2	REPEAT TEXT	Text
3	Smart Select 3	ZOOM	Eject
4	Smart Select 4	TIMER AV	AV
MOVIE	Green/Movie	B	Green
MUSIC	Red/Music	A	Red
GAME	Blue/Game	D	Blue
PURE	Yellow/Pure	C	Yellow
1	1	1	1
2	2	2	2
3	3	3	3

Original		Replacement	
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
POWER	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Up		Up
ENTER	Enter	OK	Ok
	Down		Down
	Right		Right
	Left		Left
HOME	Home	HOME SMART	Smart

Original		Replacement	
	Stop		Stop
	Pause		Pause
	Play	PLAY MODE	Play
	>>		>>
	<<		<<
TUNE +	>>I / Tune+		>>I
TUNE	I <<I / Tune-		I <<
1	Smart Select 1	E-MANUAL D.MENU	D. Menu
2	Smart Select 2	REPEAT TEXT	Text
3	Smart Select 3	ZOOM	Eject
4	Smart Select 4	TIMER AV	AV
CH / PAGE	CH/ Page+	+ CH	Ch +
	CH/ Page-	CH −	Ch -
SLEEP	Sleep	PROG SLEEP	Sleep
MUTE	Mute	MUTE	Mute
BACK	Back	RETURN BACK	Back
VOLUME	Vol +	+ VOL	Vol +

Original		Replacement		Original	Replacement
▼	Vol -	VOL –	Vol -		
CBL/SAT	CBL/SAT	SHIFT + 1	Shift + 1		
DVD	DVD	SHIFT + 2	Shift + 2		
Blu-ray	Blu-ray	SHIFT + 3	Shift + 3		
AUX	AUX	SHIFT + 4	Shift + 4		
TUNER	Tuner	SHIFT + 5	Shift + 5		
Bluetooth	Bluetooth	SHIFT + 6	Shift + 6		
GAME	Game	SHIFT + 7	Shift + 7		
8K	8K	SHIFT + 8	Shift + 8		
PHONO	Phono	SHIFT + 9	Shift + 9		
MEDIA PLAYER	Media Player	APP MEDIA	Media		
INTERNET RADIO	Internet Radio	SEARCH TV/R	TV/R		
CD	CD	-/-- GUIDE	Guide		
USB	USB	FAV PRE-CH	Pre Ch		
♫	♫	SHIFT + 0	Shift + 0		
TV AUDIO	Tv Audio	SOUND DUAL	Dual		

Original		Replacement	
POWER	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Up		Up
ENTER	Enter	OK	Ok
	Down		Down
	Right		Right
	Left		Left
1	Smart Select 1	E-MANUAL D.MENU	D. Menu

Original		Replacement	
2	Smart Select 2	REPEAT TEXT	Text
3	Smart Select 3	ZOOM	Eject
4	Smart Select 4	TIMER AV	AV
BACK	Back	RETURN BACK	Back
CH / PAGE	CH/ Page+	+ CH	Ch +
	CH/ Page-	CH −	Ch -
MUTE	Mute	MUTE	Mute
SLEEP	Sleep	PROG SLEEP	Sleep
VOLUME	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
CBL/ SAT	CBL/ SAT	SHIFT + 1	Shift + 1
DVD	DVD	SHIFT + 2	Shift + 2
Blu-ray	Blu-ray	SHIFT + 3	Shift + 3
AUX	AUX	SHIFT + 4	Shift + 4
TUNER	Tuner	SHIFT + 5	Shift + 5
Bluetooth	Bluetooth	SHIFT + 6	Shift + 6
GAME	Game	SHIFT + 7	Shift + 7

Original		Replacement		Original	Replacement
8K	8K	SHIFT + 8	Shift + 8		
PHONO	Phono	SHIFT + 9	Shift + 9		
USB	USB	FAV PRE-CH	Pre Ch		
MEDIA PLAYER	Media Player	APP MEDIA	Media		
CD	CD	-/-- GUIDE	Guide		
INTERNET RADIO	Internet Radio	SEARCH TV/R	TV/R		
	.:l:.	SHIFT + 0	Shift + 0		
HOME	Home	HOME SMART	Smart		
■	Stop	■	Stop		
II	Pause	II	Pause		
▶	Play	PLAY MODE ▶	Play		
▸▸	>>	»	>>		
◂◂	<<	«	<<		
TUNE + ▸▸I	>>I / Tune+	»I	>>I		
TUNE − I◂◂	I<< / Tune-	I«	I<<		
TV AUDIO	Tv Audio	SOUND DUAL	Dual		