Original		Replacement	
ON/STANDBY	On / Standby		Power
1 V1	Input Selector V	TV 1	1
2 V2	Input Selector V	DVD 2	2
3 V3	Input Selector V	CD-STB 3	3
5 MULTI CH	Input Selector Multi CH	TAPE 5	5
6 DVD	Input Selector	TUNER 6	6
7 TAPE	Input Selector	AUX-HDD 7	7
8 TUNER	Input Selector Tuner	USB 8	8
9 CD	Input Selector C	BLUETOOTH 9	9
0 DIMMER	Dimmer	HDMI-SAT 0	0
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
GUIDE TOP MENU	Guide/Top	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	SURROUND	Eject / Surround
ENTER	Enter	OK	OK
	Up		Up

Original		Replacement	
	Down		Down
PLAYLIST/CAT+	Right		Right
-PLAYLIST/CAT	Left		Left
	Play	SLOW	Play / Slow
	Rev. Play	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	<<	TUNE+	>> / Tune+
	>>	PRESET-	I<< / Preset-
	I<<	TUNE-	<< / Tune-
	>>I	PRESET+	>>I / Preset+
STEREO	Listening Mode Stereo	NETFLIX SEARCH	Red / Netflix / Search
SURROUND	Listening Mode Surround	APP REPEAT	Green / APP / Repeat
	Listening Mode <	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Listening Mode >	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO TEST TONE	Test Tone/Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE CH SEL	CH Sel/Subtitl	EQ SUBTITLE	Subtitle / EQ
RANDOM LEVEL-	Level-/Random	PROGRAM TV/RADIO	TV/Radio / Program

Original		Replacement	
REPEAT LEVEL+	Level +/ Repeat	SIZE ZOOM	Zoom / Size
DISPLAY	Display	ANGLE INFO	Info / Angle
L NIGHT DVD	L. Night	LIST SMART	Smart / List
CINE FLTR HDD	Cine FLTR	MEDIA DISPLAY	Display / Media
INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH DISC ALBUM +	CH/ Disc/ Album	CH +	CH+ / Page+
CH DISC ALBUM −	CH/ Disc/ Album-	CH −	CH- / Page-
VOL ▲	Vol +	VOL +	Vol +
VOL ▼	Vol -	VOL −	Vol -
I/⏻	Power Tv/ Standby	SHIFT + ⏻	Shift + Power
VOL ▲	Vol + Tv	SHIFT + VOL +	Shift + Vol +
VOL ▼	Vol - Tv	SHIFT + VOL −	Shift + Vol -
1 V1	1 Tv	SHIFT + TV 1	Shift + 1
2 V2	2 Tv	SHIFT + DVD 2	Shift + 2
3 V3	3 Tv	SHIFT + CD - STB 3	Shift + 3
4 V4	4 Tv	SHIFT + VIDEO 4	Shift + 4
5 MULTI CH	5 Tv	SHIFT + TAPE 5	Shift + 5

Original		Replacement	
6 DVD	6 Tv	SHIFT + TUNER 6	Shift + 6
7 TAPE	7 Tv	SHIFT + AUX - HDD 7	Shift + 7
8 TUNER	8 Tv	SHIFT + USB 8	Shift + 8
9 CD	9 Tv	SHIFT + BLUETOOTH 9	Shift + 9
0 DIMMER	0 Tv	SHIFT + HDMI - SAT 0	Shift + 0
+10	+10 Tv	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PREVIOUS MENU MUTING	Muting/ Previous Menu Tv	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
ENTER	Enter Tv	SHIFT + OK	Shift + OK
PLAYLIST/CAT+	Right Tv	SHIFT + ▶	Shift + Right
PLAYLIST/CAT−	Left Tv	SHIFT + ◀	Shift + Left
SETUP	Setup Tv	TOP MENU D.MENU	D. Menu / Top
▲	Up Tv	SHIFT + ▲	Shift + Up
▼	Down Tv	SHIFT + ▼	Shift + Down

Original		Replacement	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
+10	+10/10/-/--	GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CLR	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home

Original		Replacement	
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer
PLAYLIST/CAT	Left/Playlist/Ca		Left
ENTER	Enter	OK	OK
PLAYLIST/CAT	Right/Playlist/C		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-

Original	Replacement
Listening Mode >	SHIFT + PRESET+ (Shift + >>I / Preset+)
AUDIO / TEST TONE	LANG I/II / AUDIO
Audio	Audio / Lang I/II
SUBTITLE / CH SEL	EQ / SUBTITLE
Subtitle	Subtitle / EQ
RANDOM / LEVEL-	Prime Video / RANDOM
Random	Blue / Prime Video / Random
REPEAT / LEVEL+	APP / REPEAT
Repeat	Green / APP / Repeat
DISPLAY	MEDIA / DISPLAY
Display	Display / Media
PLAY MODE / VCR	FORMAT / PICTURE
Play Mode VCR	Picture / Format
L NIGHT / DVD	SHIFT + DVD 2
DVD	Shift + 2
CINE FLTR / HDD	SHIFT + AUX - HDD 7
HDD	Shift + 7

Original	Replacement

Original	Replacement
On / Standby	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
+10/10/-/--	Guide / EPG / -/--
0/11	0
12	Fav / Marker / PC
Disc+	CH+ / Page+
Vol +	Vol +
Disc-	CH- / Page-
Vol -	Vol -

Original	Replacement
Pause	Pause / Step / Freeze
Play	Play / Slow
Stop	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+
I <<	I << / Preset-
>>I	>>I / Preset+
Stereo	Audio / Lang I/II
Surround	Eject / Surround
< Listening Mode	Shift + I << / Preset-
Listening Mode >	Shift + >>I / Preset+
Random	Blue / Prime Video / Random
Repeat	Green / APP / Repeat
Display	Display / Media

Original		Replacement	
ON/STANDBY	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0/11	HDMI-SAT 0	0
CH DISC ALBUM +	CH+	CH PAGE +	CH+ / Page+
CH DISC ALBUM −	CH-	CH PAGE −	CH- / Page-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Replacement	
	<<	TUNE-	<< / Tune-
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT + PRESET-	Shift + I<< / Preset-
	Listening Mode >	SHIFT + PRESET+	Shift + >>I / Preset+
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L NIGHT DVD	L. Night	TIMER SLEEP	Sleep / Timer