Original	Replacement
Power	Power
Input	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Guide	Guide
CH. List	List
Play	Play
Red	Red
Green	Green

Original	Replacement
Yellow	Yellow
Blue	Blue
[=]	Menu
Pause	Pause
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Back	Back
Exit	Exit
Vol +	Vol +
Vol -	Vol -
Home	Smart
Micro	Media
CH+	Ch +
CH-	Ch -

Original		Replacement		Original	Replacement
SUBTITLE	Subtitle	AD SUBT	Subt		
	Mute	MUTE	Mute		
TEXT	Text	REPEAT TEXT	Text		
FREE	Free	SETTINGS OPT	Options		
SPORTS	Sports	SEARCH TV/R	TV/R		
CHILI	Chili	SOUND DUAL	Dual		
NETFLIX	Netflix	SHIFT + APP MEDIA	Shift + Media		
prime video	prime video	ECO 3D	3D		
YouTube	YouTube	FAV PRE-CH	Pre Ch		
TV	TV Tinvision	SHIFT + SEARCH TV/R	Shift + TV/R		
Rakuten TV	Rakuten Tv	E-MANUAL D.MENU	D. Menu		
Rai Play	Rai Play	SHIFT + HOME SMART	Shift + Smart		