Original		Replacement	
	Power		Power
	Power Tv	SHIFT +	Shift + Power
	Sleep	TIMER SLEEP	Sleep / Timer
	Vol + Tv	SHIFT +	Shift + Vol +
	AV Tv	RDS AV INPUT	AV / Input / RDS
	Vol - Tv	SHIFT +	Shift + Vol -
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	Vol +	VOL +	Vol +
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	Vol -	VOL -	Vol -
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9

Original		Replacement	
	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
	0	HDMI-SAT 0	0
	+10	-/-- GUIDE EPG	Guide / EPG / -/--
	Mute	DIMMER MUTE	Mute / Dimmer
	DVD	SHIFT + DVD 2	Shift + 2
	iPod	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Ext-In/Radio	APP REPEAT	Green / APP / Repeat
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	>>I	PRESET+	>>I / Preset+
	Menu/Play List	HOME MENU	Menu / Home
	Stop	HOLD	Stop / Hold
	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Start	LIST SMART	Smart / List

Original		Replacement	
	Up		Up
	Top Menu/Direct Navigator		D. Menu / Top
	Functions		Setup / OPT /
	Left		Left
	OK		OK
	Right		Right
	Play Mode/Repeat		Text / Goto
	Down		Down
	Return		Back / Return
	Sound/CH		Audio / Lang I/II
	Surround		Eject / Surround
	W.SRD		Zoom / Size
	FL. Display		Info / Angle

Original	Replacement