Original		Replacement	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
≧10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
STOP	Stop	HOLD	Stop / Hold
CD ▶/II	Play/Pause CD	SLOW ▶	Play / Slow
TAPE	Tape	SHIFT + TAPE 5	Shift + 5
FADE MUTING	Fade Muting	DIMMER MUTE	Mute / Dimmer
CLOCK/ SLEEP	Clock/Sleep	LIST SMART	Smart / List

Original		Replacement	
FM/AM	FM/AM	PROGRAM TV/ RADIO	TV/Radio /
TIMER	Timer	TIMER SLEEP	Sleep / Timer
◀◀ PI ⏮	I<<	PRESET- ⏮	I<< / Preset-
◀◀ PI ⏮	<< Preset	TUNE- ◀◀	<< / Tune-
ET ▶▶ ▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+
ET ▶▶ ▶▶I	Preset >>	TUNE+ ▶▶	>> / Tune+
ROUP/PTY ▲	Tuning/Group/PTY	+ CH PAGE	CH+ / Page+
TUNING/ ▼	Tuning/Group/PTY Down	CH PAGE −	CH- / Page-
PTY SEARCH	PTY Search	RDS AV INPUT	AV / Input / RDS
DISPLAY/ PROGRAM	Display/Progra	SHIFT + MEDIA DISPLAY	Shift + Display / Media
NEWS/INFO	News/Info	ANGLE INFO	Info / Angle
DISPLAY MODE	Display Mode	MEDIA DISPLAY	Display / Media
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
HBS	HBS	EQ SUBTITLE	Subtitle / EQ
+ VOLUME	Vol+	+ VOL	Vol+

Original	Replacement	Original	Replacement
VOLUME – Vol-	VOL – Vol-		