Mandis shop

Sony RMT-845

Original		Replacement	
TC RESET	TC Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DATA CODE	Data Code	LIST SMART	Smart / List
	Start/Stop		Power
SCAN	◁ Scan/Slow	TUNE-	<< / Tune-
SLOW	Scan/Slow ▷	TUNE+	>> / Tune+
T	T	CH PAGE +	CH+ / Page+
	⏮	PRESET- ⏮	⏮ / Preset-
	⏭	PRESET+ ⏭	⏭ / Preset+
PLAY	Play	SLOW ▶	Play / Slow
PAUSE	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
W	W	CH PAGE −	CH- / Page-
STOP	Stop	HOLD ■	Stop / Hold
	Up		Up
MODE	Mode	FORMAT PICTURE	Picture / Format
	Left		Left
ENTER	Enter	OK	OK
	Right		Right

Original		Replacement	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Down		Down

https://remotecontrols.com/Sony/1617-934-replacement-remote-control-for-Sony-RMT-845-145403.htm