Mandis shop

Panasonic N2QAYC000081

Original		Replacement	
	Power		Power
iPod	Eject iPod	SHIFT + SURROUND	Shift + Eject / Surround
CD	Eject CD	SURROUND	Eject / Surround
iPod/USB	iPod USB	LIST SMART	Smart / List
CD/RADIO	CD/Radio	PROGRAM TV/RADIO	TV/Radio /
	Bluetooth	BLUETOOTH 9	9
	I<<<< / <<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	>>/ >>I	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
VOL–	Vol -	VOL –	Vol -
VOL+	Vol +	+ VOL	Vol +
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
iPod MENU DISPLAY	Display/iPod	MEDIA DISPLAY	Display / Media
SOUND	Sound	TITLE SOUND	Sound / Title

Original		Replacement	
PLAY MENU	Play Menu	APP REPEAT	Green / APP / Repeat
	Album Up		Up
OK	OK	OK	OK
	Album Down		Down

https://remotecontrols.com/Panasonic/10654534-replacement-remote-control-for-Panasonic-N2QAYC000081.htm