Original		Replacement	
DVD/VHS	DVD/VHS Power		Power
TV	TV Power	SHIFT +	Shift + Power
CH	TV CH +	SHIFT + CH	Shift + CH+ /
VOLUME	TV Volume +	VOL	Vol +
DRIVE SELECT	Drive Select	FORMAT PICTURE	Picture / Format
AV	TV AV	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH	TV CH -	SHIFT + CH PAGE	Shift + CH- /
VOLUME	TV Volume -	VOL	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
CH	CH + / Tracking/V-Lock	CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH - / Tracking/V-Lock	CH PAGE	CH- / Page-
7	7	AUX-HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VIDEO Plus+	VIDEO Plus+	PROGRAM TV/RADIO	TV/Radio /
* RESET	* / Reset	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI-SAT 0	0
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
DELETE	Delete	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SKIP/I	I<<	PRESET-	I<< / Preset-
INDEX	>>I	PRESET+	>>I / Preset+
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
i	i	ANGLE INFO	Info / Angle
PROG/CHECK	Prog Check	OPT-TOOLS SETUP	Setup / OPT /
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Replacement	Original	Replacement
Direct Navigator	D.Menu / Top	Text	Text / Goto
Left / ◁ I	Left	STTL	Subtitle / EQ
Up	Up	Display	Display / Media
Enter / OK	OK	Time Slip / << J Rew	Shift + << /
Right / I >	Right		
Functions	Menu / Home		
Sub Menu	Smart / List		
Down	Down		
Return	Back / Return		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow / Create Chapter	Yellow / YouTube / Repeat		
Blue / Manual	Blue / Prime Video / Random		
Rec	Rec / Rec Mode		
Rec Mode	Shift + Rec / Rec Mode		
Ext Link	Sound / Title		
Direct TV Rec	Zoom / Size		