Mandis shop

VRM-60

Original		Replacement	
ON/OFF	On/Off		Power
CHANNEL >	Channel >	CH	CH+ / Page+
CHANNEL <	< Channel	CH	CH- / Page-
PLAY	Play	SLOW	Play / Slow
STOP	Stop	HOLD	Stop / Hold
PAUSE STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze
F FWD	>>/F.FWD	TUNE+	>> / Tune+
REW	<</Rew	TUNE-	<< / Tune-
REC	Rec	REC MODE	Rec / Rec Mode

Original	Replacement

https://remote-controls.ch/en/Sanyo/1067231-96924-replacement-remote-control-for-Sanyo-VRM-60.html