Mandis shop

Sony RMT831

Original	Replacement	Original	Replacement
Photo	Picture / Format	Zero Set	0
Index	Smart / List	Display	Display / Media
Power	Power		
Memory -	CH- / Page-		
Memory +	CH+ / Page+		
T	Vol +		
Search M	Setup / OPT /		
Play M	OK		
I <<	<< / Preset-		
>>I	>>I / Preset+		
W	Vol -		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
II Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Slow I>	Zoom / Size		

https://remotecontrols.com/Sony/1677-678-replacement-remote-control-for-Sony-RMT831-14395.htm