Mandis shop

RM-SEP30

Original		Replacement	
	Power		Power
VOLUME	Volume+	VOL	Vol+
MUSIC MENU	Music Menu	HOME MENU	Menu / Home
MEGA BASS	Mega Bass	TITLE SOUND	Sound / Title
VOLUME	Volume-	VOL	Vol-
TAPE	Tape	TAPE 5	5
CD/ REMAIN	CD/Remain	CD - STB 3	3
TUNER/ BAND	Tuner/Band	TUNER 6	6
PRESET	Preset +	SHIFT + PRESET+	Shift + >>I / Preset+
TUNING/ CLOCK/TIMER	Tuning/Clock/Timer +	TUNE+	>> / Tune+
TUNER MEM/ ENTER/PGM	Tuner	OK	OK
PRESET	Preset -	SHIFT + PRESET-	Shift + I<< / Preset-
TUNING/ CLOCK/TIMER	Tuning/Clock/Timer -	TUNE-	<< / Tune-
SHUFFLE	Shuffle	LIST SMART	Smart / List
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold

Original		Replacement	
	I<</<<	PRESET-	I<< / Preset-
	>>/>>I	PRESET+	>>I / Preset+
CLOCK/TIMER/ SLEEP SET	Clock/Timer/Sleep Set	TIMER SLEEP	Sleep / Timer
TIMER ON/OFF	Timer On/Off	PC FAV MARKER	Fav / Marker / PC
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

https://remote-controls.ch/en/Sony/1068212-5950-replacement-remote-control-for-Sony-RMSEP30-147682711.html