Original		Replacement	
POWER	Power		Power
EJECT	Eject	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SYSTEM	System	TOP MENU D.MENU	D. Menu / Top
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CLK/COUNT	CLK/Count	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CLR/RST	CLR/RST	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
INPUT	Input	RDS AV INPUT	AV / Input / RDS
SPEED	Speed	NETFLIX SEARCH	Red / Netflix / Search
AFT	AFT	APP REPEAT	Green / APP / Repeat
FINE	Fine Up	+ VOL	Vol +
PROG	Prog Up	+ CH PAGE	CH+ / Page+
INDEX	Index	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A.TRK	A. TRK	Prime Video RANDOM	Blue / Prime Video / Random
FINE	Fine Down	VOL −	Vol -
PROG	Prog Down	CH PAGE −	CH- / Page-
	<< Shuttle	PRESET- ⏮	I<< / Preset-
	Shuttle >>	PRESET+ ⏭	>>I / Preset+
PLAY	Play	SLOW ▶	Play / Slow
REW	<<	TUNE- ◀◀	<< / Tune-
F.F	>>	TUNE+ ▶▶	>> / Tune+
STOP	Stop	HOLD ■	Stop / Hold
REC	Rec	REC MODE ●	Rec / Rec Mode
P/S	P/S	STEP - FREEZE ⏸	Pause / Step / Freeze

Original		Replacement		Original	Replacement
MENU	Menu	HOME MENU	Menu / Home		
	Up		Up		
Q-PRO	Q-Pro	LIST SMART	Smart / List		
SOFTEN	Left / Soften / Slow-		Left		
OK	OK	OK	OK		
SHARPEN	Right / Sharpen / Slow+		Right		
PICTURE	Picture	FORMAT PICTURE	Picture / Format		
	Down		Down		
	TV/VCR	PC FAV MARKER	Fav / Marker / PC		