Mandis shop

LOG008

Original		Replacement	
	((·))	LANG I/II AUDIO	Audio / Lang I/II
	Power		Power
iPod	i Pod	USB 8	8
aux	AUX	AUX - HDD 7	7
am	am	NETFLIX SEARCH	Red / Netflix / Search
fm	fm	APP REPEAT	Green / APP / Repeat
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	[=]	HOME MENU	Menu / Home
	↵	OK	OK
+	+	+ VOL	Vol +
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow

Original		Replacement	
	Pause	STEP - FREEZE	Pause / Step / Freeze
	>>	TUNE+	>> / Tune+
-	-	VOL	Vol -
	X	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Recall	RETURN BACK	Back / Return
	Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
sleep	Sleep	TIMER SLEEP	Sleep / Timer

https://remotecontrols.com/LOGITECH/1825-362-replacement-remote-control-for-LOGITECH.html