# Mandis shop

Panasonic RC45194T

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Voice | Smart / List |
| 1 | 1 | P- | CH- / Page- |
| 2 | 2 | TV | Display / Media |
| 3 | 3 | Guide | Guide / EPG / -/-- |
| 4 | 4 | ☼ | Menu / Home |
| 5 | 5 | Up | Up |
| 6 | 6 | Left | Left |
| 7 | 7 | OK | OK |
| 8 | 8 | Right | Right |
| 9 | 9 | ← | Back / Return |
| Input | AV / Input / RDS | Down | Down |
| 0 | 0 | Exit | Exit / Cancel / Clear |
| Info | Info / Angle | Netflix | Shift + Red / Netflix / |
| Vol + | Vol + | YouTube | Shift + Yellow / YouTube / |
| Mute | Mute / Dimmer | prime video | Shift + Blue / Prime |
| P+ | CH+ / Page+ | Disney+ | Fav / Marker / PC |
| Vol - | Vol - | TikTok | Shift + Green / APP / Repeat |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| FREE | Free | FORMAT PICTURE | Picture / Format | | | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | | | |
| | Green | APP REPEAT | Green / APP / Repeat | | | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | | | |
| << | << | TUNE- | << / Tune- | | | | |
| ■ | Stop | HOLD ■ | Stop / Hold | | | | |
| >> | >> | TUNE+ | >> / Tune+ | | | | |
| ● | Rec | REC MODE ● | Rec / Rec Mode | | | | |
| ▶II | Play | SLOW ▶ | Play / Slow | | | | |
| II | Pause | STEP-FREEZE II | Pause / Step / Freeze | | | | |
| TEXT | Text | GOTO TEXT | Text / Goto | | | | |