Mandis shop

Panasonic RC45195T

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Source	AV / Input / RDS
0	0
Info	Info / Angle
Vol +	Vol +
Mute	Mute / Dimmer
P+	CH+ / Page+
Vol -	Vol -

Original	Replacement
Voice	Smart / List
P-	CH- / Page-
Home/TV	D.Menu / Top
Guide	Guide / EPG / -/--
☼	Menu / Home
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Back	Back / Return
Exit	Exit / Cancel / Clear
Netflix	Shift + Red / Netflix /
YouTube	Shift + Yellow / YouTube /
Freely	Shift + Blue / Prime
Disney+	Zoom / Size
TikTok	Shift + Green / APP / Repeat

Original		Replacement		Original		Replacement	
FREE	Free	PROGRAM TV/RADIO	TV/Radio /				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
<<	<<	TUNE- <<	<< / Tune-				
■	Stop	HOLD ■	Stop / Hold				
>>	>>	TUNE+ >>	>> / Tune+				
●	Rec	REC MODE ●	Rec / Rec Mode				
II▶	Play	SLOW ▶	Play / Slow				
II▶	Pause	STEP-FREEZE II	Pause / Step / Freeze				
TEXT	Text	GOTO TEXT	Text / Goto				