Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DTV/ATV	DTV/ATV	HOME SMART	Smart
RETURN	Return	RETURN BACK	Back
P.MODE	P.Mode	SHIFT + PICTURE FORMAT	Shift + Format
S.MODE	S.Mode	SHIFT + SOUND DUAL	Shift + Dual
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Replacement	
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
SOURCE	Source	TIMER AV	AV
DISPLAY	Display	DISPLAY INFO	Info
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
LANG/AUDIO	Lang/Audio	SOUND DUAL	Dual
RECLIST	Reclist	DISC NAV LIST	List
REC	Rec	REC MODE	Rec
FAV/LIST	FAV/List	FAV PRE-CH	Pre Ch
FREEZE	Freeze	APP MEDIA	Media
+ VOL	Vol+	+ VOL	Vol +
VOL -	Vol-	VOL –	Vol -
+ CH	CH+	+ CH	Ch +

Original		Replacement	
CH -	CH-	CH –	Ch -
EPG ◀◀	EPG	-/-- GUIDE	Guide
ASPECT ▶▶	Aspect	ECO 3D	3D
EPG ◀◀	<<	«	<<
ASPECT ▶▶	>>	»	>>
ASPECT ▶▶	Pause/Timeshift	❚❚	Pause
CANCEL ⏮	I<<Cancel	⏮	I<<
SUB.PG ⏭	>>I/Sub.Pg	⏭	>>I
INDEX ■	Stop/Index	■	Stop
TIMESHIFT ▶❚❚	Play	PLAY MODE ▶	Play
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
SUBTITLE	Subtitle	AD SUBT	Subt
REVEAL	Reveal	SETTINGS OPT	Options
SIZE	Size	PICTURE FORMAT	Format
HOLD	Hold	ZOOM ⏏	Eject
TEXT	Text	REPEAT TEXT	Text
RED	Red	A	Red

Original		Replacement	
GREEN	Green	B	Green
YELLOW	Yellow	C	Yellow
CYAN	Blue	D	Blue