Original	Replacement	Original	Replacement
Power	Power	Favor	Options
Last	Pre Ch	Menu	Menu
Mute	Mute	Sub-T	Subt
1	1	Exit	Exit
2	2	Up	Up
3	3	Down	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	CH+	Ch +
8	8	CH-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
TV/R	TV/R	Red	Red
Audio	Dual	Green	Green
Info	Info	Yellow	Yellow
Mode	D. Menu	Blue	Blue

Original		Replacement		Original	Replacement
EPG	EPG	GUIDE	Gui de		
TEXT	Text	REPEAT TEXT	Text		

Original	Replacement	Original	Replacement
Power	Power	Favor	Options
Last	Pre Ch	Menu	Menu
Mute	Mute	Sub-T	Subt
1	1	Exit	Exit
2	2	Up	Up
3	3	Down	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	CH+	Ch +
8	8	CH-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
TV/R	TV/R	Red	Red
Audio	Dual	Green	Green
Info	Info	Yellow	Yellow
Mode	D. Menu	Blue	Blue

Original	Replacement		Original	Replacement
EPG	GUIDE	Gui de		
Text	REPEAT TEXT	Text		

Original	Replacement	Original	Replacement
Power	Power	Favor	Options
Last	Pre Ch	Menu	Menu
Mute	Mute	Sub-T	Subt
1	1	Exit	Exit
2	2	Up	Up
3	3	Down	Down
4	4	Right	Right
5	5	Left	Left
6	6	OK	Ok
7	7	CH+	Ch +
8	8	CH-	Ch -
9	9	Vol +	Vol +
0	0	Vol -	Vol -
TV/R	TV/R	Red	Red
Audio	Dual	Green	Green
Info	Info	Yellow	Yellow
Mode	D. Menu	Blue	Blue

Original	Replacement		Original	Replacement
EPG	GUIDE	Gui de		
Text	REPEAT TEXT	Text		