Original	Replacement	Original	Replacement
On/Off	Power	Sp/Lp/Speed	Setup / OPT /
Audio Out	Mute / Dimmer	Video/Go-To	Text / Goto
Play	Play / Slow	Input Source	AV / Input / RDS
Pause	Pause / Step / Freeze	Menu	Menu / Home
Stop	Stop / Hold	Menu Up	Up
Record	Rec / Rec Mode	Info/Intro	Info / Angle
Rewind	<< / Tune-	Menu Left	Left
F. Forward	>> / Tune+	OK Enter	OK
Prev.	I << / Preset-	Menu Right	Right
Next	>>I / Preset+	Menu Down	Down
Audio Dub	Audio / Lang I/II	Tracking+	Vol +
Next Sv+V	Eject / Surround	VCR/TV	Smart / List
F. Adv	Picture / Format	Slow/Dpss+	CH+ / Page+
Encode	Zoom / Size	Tracking-	Vol -
T. Set/Clock	Sleep / Timer	Display	Display / Media
Progr/C/CH	TV/Radio /	Slow/Dpss-	CH- / Page-
Auto/Track	D. Menu / Top Menu	1	1

https://remote-controls.com/Amstrad/10653-Amstrad-DD-8904-equivalent-remote-control.html

Original	Replacement	Original	Replacement
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
-/--	Guide / EPG / -/--		
0	0		
Counter/Memor	Red / Netflix / Search		
Counter Stop	Green / APP / Repeat		
Counter Reset	Yellow / YouTube / Repeat		
On/Off	+ Shift + Power		
X2 Rew/Play	+ Shift + Play /		
P. Back/R. +Play	+ Shift + Pause / Step /		
Slow Down	+ Shift + Left		