Original		Replacement	
	Power		Power
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
WIDE	Wide	FORMAT PICTURE	Picture / Format
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow/ ><	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original		Replacement	
MENU	Menu	HOME MENU	Menu / Home
9	9	BLUETOOTH 9	9
0	0/ AV	RDS AV INPUT	AV / Input / RDS
0	0/ AV	HDMI - SAT 0	0
i	i	ANGLE INFO	Info / Angle
▲	Up	▲	Up
CANCEL	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
◄	Left	◄	Left
►	Right	►	Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▼	Down	▼	Down
OK	OK	OK	OK
OK	Play	SLOW ►	Play / Slow
OK	Pause	STEP - FREEZE II	Pause / Step / Freeze
LANG(AD)	Lang(AD)	LANG I/II AUDIO	Audio / Lang I/II
SUBT	Subt.	EQ SUBTITLE	Subtitle / EQ
FAV	FAV	PC FAV MARKER	Fav / Marker / PC

Original		Replacement		Original	Replacement
TV/RADIO	Tv/ Radi o	PROGRAM TV/ RADIO	TV/ Radi o /		
P+	P+	CH PAGE +	CH+ / Page+		
V+	Vol +	VOL +	Vol +		
GUIDE	Gui de	-/-- GUIDE EPG	Gui de / EPG / -/--		
	Mut e	DIMMER MUTE	Mut e / Di mmer		
TEXT	Text	GOTO TEXT	Text / Got o		
P-	P-	CH PAGE −	CH- / Page-		
V-	Vol -	VOL −	Vol -		