Original		Replacement		Original	Replacement
	Power		Power		
AUX	AUX	A	Red		
DIGITAL	Digital	D	Blue		
	Bluetooth	B	Green		
	Play	PLAY MODE	Play		
	Pause		Pause		
	>>I		>>I		
	I<<		I<<		
	Vol+	+ VOL	Vol +		
	Vol-	VOL −	Vol -		

https://remote-controls.ch/en/CREATIVE/1062147-89784-replacement-remote-control-for-CREATIVE-T4.html