Original		Replacement	
STANDBY	Power		Power
DTV/VCR	DTV/ VCR	HOME SMART	Smart
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	FAV PRE-CH	Pre Ch
RECALL	Recall	RETURN BACK	Back
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Replacement	
INFO	Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
EPG	EPG	-/-- GUIDE	Guide
EXIT	Exit	CLEAR EXIT	Exit
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	CH+	CH +	Ch +
	CH-	CH -	Ch -
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
TEXT	Text	REPEAT TEXT	Text
PAUSE	Pause		Pause
	Red	A	Red
	Green	B	Green

Original		Replacement		Original		Replacement	
TV/RADIO	Yel l ow	C	Yel l ow				
	Bl ue	D	Bl ue				
TV/RADIO	Tv/ Radi o	SEARCH TV/R	TV/ R				