Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
MENU	Menu	HOME MENU	Menu / Home
0	0	HDMI - SAT 0	0
LAST	Last	RETURN BACK	Back / Return
TV/R	Tv/R	PROGRAM TV/ RADIO	TV/Radio /
CH▲	Up		Up
CH▲	CH+	+ CH PAGE	CH+ / Page+

Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL ◀	Left		Left
VOL ◀	Vol -	VOL −	Vol -
OK	OK	OK	OK
VOL ▶	Right		Right
VOL ▶	Vol +	+ VOL	Vol +
SUB-T	Sub-T.	EQ SUBTITLE	Subtitle / EQ
CH▼	Down		Down
CH▼	CH-	CH PAGE −	CH- / Page-
INFO	Info	ANGLE INFO	Info / Angle
TEXT	Text	GOTO TEXT	Text / Goto
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
TIMER	Timer	TIMER SLEEP	Sleep / Timer
FAVOR	Favor	PC FAV MARKER	Fav / Marker / PC
⏮	Red/I <<	PRESET- ⏮	I << / Preset-
⏮	Red/I <<	NETFLIX SEARCH	Red / Netflix / Search
◀◀	Green/<<	TUNE- ◀◀	<< / Tune-

Original	Replacement	Original	Replacement
Green/ <<	APP / REPEAT — Green / APP / Repeat		
Yellow/ >>	TUNE+ — >> / Tune+		
Yellow/ >>	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
Blue/ >>I	Prime Video / RANDOM — Blue / Prime Video / Random		
Blue/ >>I	PRESET+ — >>I / Preset+		
USB	SHIFT + USB 8 — Shift + 8		
Rec	REC MODE — Rec / Rec Mode		
Stop	HOLD — Stop / Hold		
Play	SLOW — Play / Slow		
Pause	STEP-FREEZE — Pause / Step / Freeze		