Original		Replacement	
AMPLIFIER POWER	Amplifier Power		Power
CD POWER	CD Power	SHIFT +	Shift + Power
1	1	TV 1	1
DISC LAYER	Disc Layer	SURROUND	Eject / Surround
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
ENTER	Enter	OK	OK
	Right		Right
	Left		Left

Original		Replacement	
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
FOLDER+	Folder+		Up
FOLDER–	Folder-		Down
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
	Vol +	VOL +	Vol +
	Vol -	VOL –	Vol -
	Stop	HOLD ■	Stop / Hold
	<<	TUNE- ◀◀	<< / Tune-
	>>	TUNE+ ▶▶	>> / Tune+
	Play	SLOW ▶	Play / Slow
	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
	I <<	PRESET- ⏮	I << / Preset-
	>>I	PRESET+ ⏭	>>I / Preset+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
CALL	Call	MEDIA DISPLAY	Display / Media
TIME	Time	TIMER SLEEP	Sleep / Timer

Original	Replacement	Original	Replacement
RANDOM Random	Prime Video / RANDOM Blue / Prime Video / Random		
CLEAR Clear	CLEAR / EXIT / CANCEL Exit / Cancel / Clear		
TITLE / ARTIST Title/Artist	TITLE / SOUND Sound / Title		
MODE SELECT Mode Select	LIST / SMART Smart / List		
PROGRAM / DIRECT Program/Direct	PROGRAM / TV/RADIO TV/Radio /		
INPUT SELECT Input Select U	CH PAGE + CH+ / Page+		
INPUT SELECT Input Select Dow	CH PAGE – CH- / Page-		
TUNER PRESET Tuner Preset-	SHIFT + PRESET- Shift + I<< / Preset-		
TUNER PRESET Tuner Preset+	SHIFT + PRESET+ Shift + >>I / Preset+		