Mandis shop

Denon RC-235

Original		Replacement	
RANDOM	Random	HOME SMART	Smart
DISPLAY	Display	DISPLAY INFO	Info
PROG/DIRECT	Prog/Direct	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	-/-- GUIDE	Guide
CALL	Call	FAV PRE-CH	Pre Ch
VOLUME	Vol+	+ VOL	Vol +
VOLUME	Vol-	VOL −	Vol -

Original		Replacement	
PLAY	Play	PLAY MODE ▶	Play
PAUSE	Pause	⏸	Pause
STOP	Stop	■	Stop
⏮	I<<	⏮	I<<
⏭	>>I	⏭	>>I
◀◀	<<	◀◀	<<
▶▶	>>	▶▶	>>
PITCH −	Pitch-	CH −	Ch -
PITCH +	Pitch+	+ CH	Ch +

https://remote-controls.ch/en/Denon/1062722-91682-replacement-remote-control-for-Denon-RC-235.html