Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
1	1	P+	Up
2	2	-	Left
3	3	-	Vol -
PIP	Smart / List	OK	OK
4	4	+	Right
5	5	+	Vol +
6	6	TXT	Text / Goto
[<>]	Picture / Format	P-	CH- / Page-
7	7	P-	Down
8	8	AV	AV / Input / RDS
9	9	Scan/ [ ]	Setup / OPT /
-/--	Guide / EPG / -/--	PAP/ Pause	Display / Media
0	0	Size/ Stop	Zoom / Size
Mute	Mute / Dimmer	Pos/ Play	D. Menu / Top
i	Info / Angle	Red/ I <	Red / Netflix / Search
Z	Menu / Home	Green/ >I	Green / APP / Repeat

Original	Replacement	Original	Replacement
Yellow/ Pause/ <	Yellow / YouTube / Repeat		
Blue/ >>	Blue / Prime Video / Random		

Original	Replacement	Original	Replacement
Power	Power	P+	Up
1	1	-	Left
2	2	-	Vol -
3	3	OK	OK
PIP	Smart / List	+	Right
4	4	+	Vol +
5	5	TXT	Text / Goto
6	6	P-	CH- / Page-
[<>]	Picture / Format	P-	Down
7	7	AV	AV / Input / RDS
8	8	Scan/[']	Setup / OPT /
9	9	PAP/ Pause	Pause / Step / Freeze
-/--	Guide / EPG / -/--	Size/ Stop	Stop / Hold
0	0	Pos/ Play	Play / Slow
i	Info / Angle	Red/ I <	I << / Preset-
Z	Menu / Home	Green/ >I	>>I / Preset+
P+	CH+ / Page+	Yellow/ Pause/ <	<< / Tune-

Original	Replacement	Original	Replacement
Bl ue/ >>	>> / Tune+		

Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
1	1	P+	Up
2	2	-	Left
3	3	-	Vol -
PIP	Smart / List	OK	OK
4	4	+	Vol +
5	5	+	Right
6	6	TXT	Text / Goto
[<>]	Picture / Format	P-	CH- / Page-
7	7	P-	Down
8	8	AV	AV / Input / RDS
9	9	Scan/ [ ]	Setup / OPT /
-/--	Guide / EPG / -/--	PAP/ Pause	Pause / Step / Freeze
0	0	Size/ Stop	Stop / Hold
Mute	Mute / Dimmer	Pos/ Play	Play / Slow
i	Info / Angle	Red/ I <	I << / Preset-
Z	Menu / Home	Green/ >I	>>I / Preset+

Original	Replacement	Original	Replacement
Yel l ow/ <<	TUNE- << / Tune-		
Bl ue/ >>	TUNE+ >> / Tune+		

Original	Replacement	Original	Replacement
Power	Power	P+	Up
1	1	-	Vol -
2	2	-	Left
3	3	OK	OK
PIP	Smart / List	+	Vol +
4	4	+	Right
5	5	TXT	Text / Goto
6	6	P-	CH- / Page-
[<>]	Picture / Format	P-	Down
7	7	AV	AV / Input / RDS
8	8	Scan/[']	Setup / OPT /
9	9	PAP/ Pause	Pause / Step / Freeze
-/--	Guide / EPG / -/--	Size/ Stop	Stop / Hold
0	0	Pos/ Play	Play / Slow
i	Info / Angle	Red/ I <	I << / Preset-
Z	Menu / Home	Green/ >I	>>I / Preset+
P+	CH+ / Page+	Yellow/ Pause/ <	<< / Tune-

https://remote-controls.de/n/10613-7869-replacement-remote-control-for-Tele-Pilot-160-C/2017/1390.htm

Pag. 7 / 8

Original	Replacement	Original	Replacement
Bl ue/ >>	>> / Tune+		