Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	FAV		Pre Ch
	TXT		Text
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Original		Replacement	
	Guide		Guide
	?		Dual
	Exit		Exit
	Menu		Menu
	Tools		Options
	Back		Back
	@		Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute
	Source		AV
	P+		Ch +

Original		Replacement	
P	P-	CH –	Ch -
	I <		I <<
	>I		>>I
	<<		<<
	>>		>>
	Rec	REC MODE	Rec
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
3D	3D	ECO 3D	3D
	OQ	PICTURE FORMAT	Format
	[. . .] . .	AD SUBT	Subt
NETFLIX	Netflix	SHIFT + APP MEDIA	Shift + Media
MY MEDIA	My Media	APP MEDIA	Media

Original	Replacement