Original	Replacement	Original	Replacement
AVR Power On	Power	OK	OK
Mute	Mute / Dimmer	Right	Right
Play	Play / Slow	Back/Exit	Exit / Cancel / Clear
Pause	Pause / Step / Freeze	Down	Down
Stop	Stop / Hold	Last	Back / Return
<<	<< / Tune-	Vol +	Vol +
>>	>> / Tune+	AVR	Smart / List
I <<	I << / Preset-	CH/Page Up	CH+ / Page+
>>I	>>I / Preset+	Vol -	Vol -
Audio Effects	Audio / Lang I/II	CH/Page Down	CH- / Page-
Surround Modes	Eject / Surround	1	1
Video Modes	Picture / Format	2	2
Sleep	Sleep / Timer	3	3
Menu	Menu / Home	4	4
Up	Up	5	5
Info	Info / Angle	6	6
Left	Left	7	7

Original	Replacement
8	USB 8 8
9	BLUETOOTH 9 9
0	HDMI - SAT 0 0
Red	NETFLIX SEARCH Red / Netflix / Search
Green	APP REPEAT Green / APP / Repeat
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat
Blue	Prime Video RANDOM Blue / Prime Video / Random
AVR Power Off	SHIFT + Power Shift + Power
Tv	SHIFT + TV 1 Shift + 1
Blu-ray	SHIFT + DVD 2 Shift + 2
DVR	SHIFT + CD - STB 3 Shift + 3
iPod	SHIFT + VIDEO 4 Shift + 4
Network	SHIFT + TAPE 5 Shift + 5
Radio	SHIFT + TUNER 6 Shift + 6
AUX	SHIFT + AUX - HDD 7 Shift + 7
Game	SHIFT + USB 8 Shift + 8
Media Server	SHIFT + BLUETOOTH 9 Shift + 9

Original	Replacement
Cable/Sat	SHIFT + HDMI - SAT 0 Shift + 0

Original	Replacement	Original	Replacement
1	1	Mute	Mute / Dimmer
DVR	Display / Media	Vol +	Vol +
DVR Power On	Power	Vol -	Vol -
2	2	CH/Page Up	CH+ / Page+
3	3	CH/Page Down	CH- / Page-
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Menu	Menu / Home		
Up	Up		
Down	Down		
Right	Right		
Left	Left		

Original	Replacement	Original	Replacement
Bluray Power	Power	Down	Down
Mute	Mute / Dimmer	Last	Back / Return
Play	Play / Slow	Vol +	Vol +
Pause	Pause / Step / Freeze	Vol -	Vol -
Stop	Stop / Hold	Blu-ray	Display / Media
Rec	Rec / Rec Mode	1	1
<<	<< / Tune-	2	2
>>	>> / Tune+	3	3
I <<	I << / Preset-	4	4
>>I	>>I / Preset+	5	5
Disc Menu	D. Menu / Top	6	6
Menu	Menu / Home	7	7
Up	Up	8	8
Left	Left	9	9
OK	OK	0	0
Right	Right	Red	Red / Netflix / Search
Back/Exit	Exit / Cancel / Clear	Green	Green / APP / Repeat

Original	Replacement	Original	Replacement
Yellow	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM Blue / Prime Video / Random		
Bluray Power Off	SHIFT + Power Shift + Power		

Original		Replacement		Original		Replacement	
ON AVR P	AVR Power On		Power		Right		Right
OFF R Power	AVR Power Off	SHIFT +	Shift + Power		Left		Left
1	1	TV 1	1	OK	OK	OK	OK
2	2	DVD 2	2	A	Red	NETFLIX SEARCH	Red / Netflix / Search
3	3	CD - STB 3	3	B	Green	APP REPEAT	Green / APP / Repeat
4	4	VIDEO 4	4	C	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
5	5	TAPE 5	5	D	Blue	Prime Video RANDOM	Blue / Prime Video / Random
6	6	TUNER 6	6	VOL +	Vol +	VOL +	Vol +
7	7	AUX - HDD 7	7	VOL -	Vol -	VOL −	Vol -
8	8	USB 8	8	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
9	9	BLUETOOTH 9	9	CH Page	CH/Page Up	CH PAGE +	CH+ / Page+
0	0	HDMI - SAT 0	0	CH Page	CH/Page Down	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home	II	Pause	STEP - FREEZE II	Pause / Step / Freeze
BACK/ EXIT	Back/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear	I<<	I<<	PRESET- I<<	I<< / Preset-
LAST	Last	RETURN BACK	Back / Return	>>I	>>I	PRESET+ >>I	>>I / Preset+
▲	Up	▲	Up	▶	Play	SLOW ▶	Play / Slow
▼	Down	▼	Down	<<	<<	TUNE- <<	<< / Tune-

Original	Replacement
>>	>> / Tune+
Stop	Stop / Hold
Rec	Rec / Rec Mode
Info	Info / Angle
Sleep	Sleep / Timer
AVR	Smart / List
Audio Effects	Audio / Lang I/II
Video Modes	Picture / Format
Surround Modes	Eject / Surround
Cable/SAT	SHIFT + 0 (Shift + 0)
Blu-ray	SHIFT + 2 (Shift + 2)
iPod	SHIFT + 4 (Shift + 4)
Radio	SHIFT + 6 (Shift + 6)
TV	SHIFT + 1 (Shift + 1)
AUX	SHIFT + 7 (Shift + 7)
DVR	SHIFT + 3 (Shift + 3)
Game	SHIFT + 8 (Shift + 8)

Original	Replacement
Media Server	SHIFT + 9 (Shift + 9)
Network	SHIFT + 5 (Shift + 5)