Original		Replacement	
AVR Power On		Power	
AVR Power Off		SHIFT +	Shift + Power
Cable/Sat		SHIFT + HDMI - SAT 0	Shift + 0
Disc		SHIFT + DVD 2	Shift + 2
DVR		SHIFT + CD - STB 3	Shift + 3
Radio		SHIFT + TUNER 6	Shift + 6
TV		SHIFT + TV 1	Shift + 1
USB		SHIFT + USB 8	Shift + 8
Game		SHIFT + VIDEO 4	Shift + 4
Media Server		SHIFT + BLUETOOTH 9	Shift + 9
Network		SHIFT + TAPE 5	Shift + 5
AUX		SHIFT + AUX - HDD 7	Shift + 7
Audio Effects		LANG I/II AUDIO	Audio / Lang I/II
Video Modes		FORMAT PICTURE	Picture / Format
Surround Modes		SURROUND	Eject / Surround
1		TV 1	1
2		DVD 2	2

Original		Replacement	
3		CD - STB 3	3
4		VIDEO 4	4
5		TAPE 5	5
6		TUNER 6	6
7		AUX - HDD 7	7
8		USB 8	8
9		BLUETOOTH 9	9
Last		RETURN BACK	Back / Return
0		HDMI - SAT 0	0
Back/Exit		CLEAR EXIT CANCEL	Exit / Cancel / Clear
Up			Up
Menu		HOME MENU	Menu / Home
Left			Left
OK		OK	OK
Right			Right
Down			Down
Red		NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
Green	Green / APP / Repeat	Sleep	Sleep / Timer
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/Page Up	CH+ / Page+		
Vol -	Vol -		
CH/Page Down	CH- / Page-		
I<<	I<< / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Stop	Stop / Hold		
AVR	Smart / List		
Info	Info / Angle		

Original		Replacement	
Disc Power On		Power	
Disc Power Off		Shift + Power	
Disc		Display / Media	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
Last		Back / Return	
0		0	
Back/Exit		Exit / Cancel / Clear	
Up		Up	
Menu		Menu / Home	

Original		Replacement	
Left		Left	
OK		OK	
Right		Right	
Down		Down	
Disc Menu		D.Menu / Top	
Red		Red / Netflix / Search	
Green		Green / APP / Repeat	
Yellow		Yellow / YouTube / Repeat	
Blue		Blue / Prime Video / Random	
Vol +		Vol +	
Mute		Mute / Dimmer	
Vol -		Vol -	
I<<		I<< / Preset-	
Pause		Pause / Step / Freeze	
>>I		>>I / Preset+	
<<		<< / Tune-	
Play		Play / Slow	

Original	Replacement	Original	Replacement
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		

Original	Replacement	Original	Replacement
DVR Power On	Power	Vol +	Vol +
DVR	Display / Media	Mute	Mute / Dimmer
1	1	CH/Page Up	CH+ / Page+
2	2	Vol -	Vol -
3	3	CH/Page Down	CH- / Page-
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Up	Up		
Menu	Menu / Home		
Left	Left		
Right	Right		
Down	Down		

Original		Replacement	
AVR Power On		Power	
AVR Power Off		SHIFT +	Shift + Power
Cable/SAT		SHIFT + HDMI - SAT 0	Shift + 0
Disc		SHIFT + DVD 2	Shift + 2
DVR		SHIFT + CD - STB 3	Shift + 3
Radio		SHIFT + TUNER 6	Shift + 6
TV		SHIFT + TV 1	Shift + 1
USB		SHIFT + USB 8	Shift + 8
Game		SHIFT + VIDEO 4	Shift + 4
Media Server		SHIFT + BLUETOOTH 9	Shift + 9
Network		SHIFT + TAPE 5	Shift + 5
AUX		SHIFT + AUX - HDD 7	Shift + 7
Audio Effects		LANG I/II AUDIO	Audio / Lang I/II
Video Modes		FORMAT PICTURE	Picture / Format
Surround Modes		SURROUND	Eject / Surround
1		TV 1	1
2		DVD 2	2

Original		Replacement	
3		CD - STB 3	3
4		VIDEO 4	4
5		TAPE 5	5
6		TUNER 6	6
7		AUX - HDD 7	7
8		USB 8	8
9		BLUETOOTH 9	9
Last		RETURN BACK	Back / Return
0		HDMI - SAT 0	0
Back/Exit		CLEAR EXIT CANCEL	Exit / Cancel / Clear
Up			Up
Menu		HOME MENU	Menu / Home
Left			Left
OK		OK	OK
Right			Right
Down			Down
Red		NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
Green	Green / APP / Repeat	Info	Info / Angle
Yellow	Yellow / YouTube / Repeat	Sleep	Sleep / Timer
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/Page Up	CH+ / Page+		
Vol -	Vol -		
CH/Page Down	CH- / Page-		
I <<	I << / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
AVR	Smart / List		