Original		Replacement	
	Power		Power
	Tv/VCR		Smart / List
	Audio		Audio / Lang I/II
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	X/0000		Exit / Cancel / Clear
	0/AUX		0
	Timer		Sleep / Timer
	'/''		Info / Angle
	Prog+		CH+ / Page+

Original		Replacement	
	Vol -		Vol -
	Vol +		Vol +
	Prog-		CH- / Page-

Original		Replacement	
Power		Power	
Review		Display / Media	
Tv/VCR		Smart / List	
Audio		Audio / Lang I/II	
--:--		Guide / EPG / -/--	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
X/0000		Exit / Cancel / Clear	
0/AUX		0	
Timer		Sleep / Timer	

Original		Replacement	
Start Debut+		SHIFT + 1	Shift + 1
Stop Fin+		SHIFT + 2	Shift + 2
Date+		SHIFT + 3	Shift + 3
Start Debut-		SHIFT + 4	Shift + 4
Stop Fin-		SHIFT + 5	Shift + 5
Date-		SHIFT + 6	Shift + 6
Prog		TV/Radio /	
Timer/?		SHIFT + SLEEP	Shift + Sleep / Timer
' /''		INFO	Info / Angle
30Sec >>		SHIFT + TUNE+	Shift + >> /
<<		TUNE-	<< / Tune-
Play		SLOW	Play / Slow
>>		TUNE+	>> / Tune+
Rec		REC MODE	Rec / Rec Mode
Stop		HOLD	Stop / Hold
Pause		STEP-FREEZE	Pause / Step / Freeze
Menu		HOME MENU	Menu / Home

Original		Replacement	
	OK		OK
	Up/Tv Prog+		Up
	Up/Tv Prog+		CH+ / Page+
	Left/I <<-		Left
	Left/I <<-		I << / Preset-
	Right/ >>I / +		Right
	Right/ >>I / +		>>I / Preset+
	Down/Tv Prog-		Down
	Down/Tv Prog-		CH- / Page-

Original	Replacement

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Prog+		CH+ / Page+
	Prog-		CH- / Page-

Original	Replacement