Mandis shop

RC-1000C

Original		Replacement	
1 LIN	Line 1		Power
NE 2	Line2	DIMMER MUTE	Mute / Dimmer
BALANCED	Balanced	SLOW	Play / Slow
1 TA	Tape1	STEP-FREEZE	Pause / Step / Freeze
PE 2	Tape 2	HOLD	Stop / Hold
PHONO	Phono	REC MODE	Rec / Rec Mode
SOURCE DIRECT ON/OFF	Source Direct On/Off	TUNE-	<< / Tune-

Original	Replacement

https://remote-controls.ch/en/Kenwood/1066924-93672-replacement-remote-control-for-Kenwood-RC-1000C.html