Mandis shop

RC-420

Original		Replacement	
	Phone		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	DNPP/SBF		Stop / Hold
	I<< Tune Track		I<< / Preset-
	>>I Tune Track		>>I / Preset+
	ATT		Eject / Surround
	SRC		AV / Input / RDS
	FM/Disc+/#		Up
	ANG		Info / Angle
	Direct/OK		OK
	AM/Disc-/*		Down
	Vol+		Vol+
	Vol-		Vol-
	1		1
	2		2
	3		3

Original		Replacement	
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

https://remote-controls.ch/en/Kenwood/1067613-537-replacement-remote-control-for-Kenwood-RC-420-A70205505.html