Original	Replacement	Original	Replacement
Power	Power	Subtitle	Subtitle / EQ
OK	OK	Settings	Setup / OPT /
Up	Up	>>	>>I / Preset +
Down	Down	>>	>> / Tune+
Right	Right	Play	Play / Slow
Left	Left	AD / PIP	Sound / Title
Back	Back / Return	<<	I << / Preset-
Vol +	Vol +	<<	<< / Tune-
Vol -	Vol -	Rec	Rec / Rec Mode
Home / Smart	Menu / Home	Pause	Pause / Step / Freeze
3D	Shift + 3	Text	Text / Goto
Mute	Mute / Dimmer	FAV	Fav / Marker / PC
P +	CH+ / Page+	Exit	Exit / Cancel / Clear
P -	CH- / Page-	Input	AV / Input / RDS
Ratio	Picture / Format	Blue	Blue / Prime Video / Random
List	Smart / List	Yellow	Yellow / YouTube / Repeat
Q. Menu	D. Menu / Top Menu	Stop / Live TV	Stop / Hold

Original	Replacement	Original	Replacement
AV Mode	SHIFT + RDS AV INPUT Shift + AV / Input / RDS	5	TAPE 5 5
Green	APP REPEAT Green / APP / Repeat	Q. View	SHIFT + MEDIA DISPLAY Shift + Display / Media
Red	NETFLIX SEARCH Red / Netflix / Search	4	VIDEO 4 4
0	HDMI - SAT 0 0	Live Zoom	SIZE ZOOM Zoom / Size
AD	LANG I/II AUDIO Audio / Lang I/II	3	CD - STB 3 3
TV / PC	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	2	DVD 2 2
Search	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /	1	TV 1 1
App	SHIFT + APP REPEAT Shift + Green / APP /	T. Opt	SHIFT + OPT-TOOLS SETUP Shift + Setup / OPT / Tools
TV / Radio	PROGRAM TV/ RADIO TV/ Radio /	Energy Saving	SURROUND Eject / Surround
Guide	-/-- GUIDE EPG Guide / EPG / -/--	My APPS	SHIFT + LIST SMART Shift + Smart / List
Info	ANGLE INFO Info / Angle		
Recent	TIMER SLEEP Sleep / Timer		
9	BLUETOOTH 9 9		
8	USB 8 8		
7	AUX - HDD 7 7		
Live Menu	MEDIA DISPLAY Display / Media		
6	TUNER 6 6		