Mandis shop

LaCi e LACI NEMAPLAYHD

Original	Replacement	Original	Replacement
POWER	Power	INFO	Info / Angle
HOME	Menu / Home	SETTINGS	Setup / OPT /
SKIP PREV.	I<< / Preset-	VOL+	Vol +
SKIP NEXT	>>I / Preset+	SEARCH	Red / Netflix / Search
STOP	Stop / Hold	PAGE UP	CH+ / Page+
PLAY	Play / Slow	VOL-	Vol -
PAUSE	Pause / Step / Freeze	EJECT	Eject / Surround
MUTE	Mute / Dimmer	PAGE DOWN	CH- / Page-
BACK	Back / Return		
FAV	Fav / Marker / PC		
UP	Up		
REW	<< / Tune-		
LEFT	Left		
OK	OK		
FWD	>> / Tune+		
RIGHT	Right		
DOWN	Down		

https://remotecontrols.com/LaCie/1553-239-replacement-remote-control-for-LaCie-20024.htm