Original		Replacement	
	Power		Power
	[ ]	AD SUBT	Subt
	Audio	SOUND DUAL	Dual
SV	[■] / SV	SEARCH TV/R	TV/R
LP V=	V≡/ LP	FAV PRE-CH	Pre Ch
000	[≡] / 000	-/-- GUIDE	Guide
	Mute/Timer	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
II T	Pause	II	Pause
II T	T	SETTINGS OPT	Options
M	M	TOP MENU MENU	Menu
E	E	CLEAR EXIT	Exit
i	i	DISPLAY INFO	Info
i	Rec	REC MODE	Rec
	UP		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Stop	■	Stop
	<<	<<	<<

Original	Replacement	Original	Replacement
Pl ay	Pl ay		
>>	>>		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	M	TOP MENU MENU	Menu
	E	CLEAR EXIT	Exit
	i	DISPLAY INFO	Info
	Rec	REC MODE	Rec
	Pause		Pause
	T	SETTINGS OPT	Options

Original		Replacement	
	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	<<		<<
	Stop		Stop
	Play	PLAY MODE	Play
	>>		>>
	Mute/Timer	MUTE	Mute
	Audio	SOUND DUAL	Dual
	[ ]	AD SUBT	Subt
	[■]/SV	SEARCH TV/R	TV/R

Original		Replacement		Original		Replacement	
LP V=	V≡/ LP	FAV PRE-CH	Pre Ch				
000	[≡] / 000	-/-- GUIDE	Guide				

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red		Red

Original		Replacement	
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	Stop		Stop
	Play		Play
	>>		>>
	Pause		Pause
	T		Options
	M		Menu
	E		Exit
	Mute/Timer		Mute
	[≡] / 000		Guide
	V≡/ LP		Pre Ch
	[■] / SV		TV/R
	Audio		Dual
	[ ]		Subt