Original	Replacement	Original	Replacement
Audio	Audio / Lang I/II	Pause/T	Pause / Step / Freeze
[ ]	Picture / Format	M	Menu / Home
Power	Power	E	Exit / Cancel / Clear
PIP	Zoom / Size	Info	Info / Angle
V=	D. Menu / Top	Up	Up
[≡]	Guide / EPG / -/--	Left	Left
Mute	Mute / Dimmer	OK	OK
1	1	Right	Right
2	2	Down	Down
3	3	Red	Red / Netflix / Search
4	4	Blue	Blue / Prime Video / Random
5	5	Green	Green / APP / Repeat
6	6	Yellow	Yellow / YouTube / Repeat
7	7		
8	8		
9	9		
0	0		

Original	Replacement	Original	Replacement
Audio	Audio / Lang I/II	0	0
[ ]	Picture / Format	Pause/T	Pause / Step / Freeze
Power	Power	M	Menu / Home
SV/[*]	Zoom / Size	E	Exit / Cancel / Clear
LP/V=	Setup / OPT /	Rec/i	Info / Angle
000/[≡I]	Guide / EPG / -/--	Up	Up
Timer/Mute	Sleep / Timer	Left	Left
Timer/Mute	Mute / Dimmer	OK	OK
1	1	Right	Right
2	2	Down	Down
3	3	<<	<< / Tune-
4	4	>>	>> / Tune+
5	5	Stop	Stop / Hold
6	6	Play	Play / Slow
7	7		
8	8		
9	9		

Original	Replacement	Original	Replacement
Audio	Audio / Lang I/II	E	Exit / Cancel / Clear
[ ]	Picture / Format	Rec	Rec / Rec Mode
Power	Power	Up	Up
SV	Display / Media	Left	Left
LP	Smart / List	OK	OK
Timer	TV/Radio /	Right	Right
1	1	Down	Down
2	2	<<	<< / Tune-
3	3	>>	>> / Tune+
4	4	Stop	Stop / Hold
5	5	Play	Play / Slow
6	6		
7	7		
8	8		
9	9		
000	0		
M	Menu / Home		