Original	Replacement
Standby	Power
Subtitle	Subtitle / EQ
Audio	Audio / Lang I/II
Mute	Mute / Dimmer
<<	<< / Tune-
Play / Pause	Play / Slow
Play / Pause	Pause / Step / Freeze
I<<	I<< / Preset-
>>	>> / Tune+
Stop	Stop / Hold
>>I	>>I / Preset+
Menu	Menu / Home
Up / CH+	Up
Up / CH+	CH+ / Page+
Exit	Exit / Cancel / Clear
Left / Vol-	Left
Left / Vol-	Vol-

Original	Replacement
OK	OK
Right / Vol+	Vol+
Right / Vol+	Right
Record	Rec / Rec Mode
Down / CH-	CH- / Page-
Down / CH-	Down
Timeshift	Sleep / Timer
1	1
2	2
3	3
--	Guide / EPG / -/--
4	4
5	5
6	6
Recall	Back / Return
7	7
8	8

Original		Replacement		Original	Replacement
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
FAV	--	PC FAV MARKER	Fav / Marker / PC		
DEVICE	Device	LIST SMART	Smart / List		
FILE	File	MEDIA DISPLAY	Display / Media		
REPEAT	Repeat	SHIFT +	APP REPEAT Shift + Green / APP /		
TELETEXT	Teletext	GOTO TEXT	Text / Goto		
DIGEST	Mosaic	FORMAT PICTURE	Picture / Format		
TV/RADIO	TV/Radio	PROGRAM TV/ RADIO	TV/Radio /		
INFO	Info	ANGLE INFO	Info / Angle		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		