Original		Replacement		Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer	VOLUME	Vol +	VOL +	Vol +
ON/STANDBY	On/Standby		Power	CH / PAGE	CH-	CH PAGE –	CH- / Page-
CBL/SAT	CBL/SAT	HDMI - SAT 0	0	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DVD	DVD	DVD 2	2	VOLUME	Vol -	VOL –	Vol -
Blu-ray	Blu-ray	VIDEO 4	4	INFO	Info	ANGLE INFO	Info / Angle
GAME	Game	PC FAV MARKER	Fav / Marker / PC	OPTION	Option	SHIFT +	OPT-TOOLS SETUP Shift + Setup / OPT / Tools
AUX	AUX	AUX - HDD 7	7	OPTION	Option	HOME MENU	Menu / Home
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media		Up		Up
TV AUDIO	TV Audio	TV 1	1		Left		Left
CD	CD	CD - STB 3	3	ENTER	Enter	OK	OK
TUNER	Tuner	TUNER 6	6		Right		Right
iPod /USB	iPod/USB	USB 8	8	BACK	Back	RETURN BACK	Back / Return
PHONO	Phono	-/-- GUIDE EPG	Guide / EPG / -/--		Down		Down
M-XPort	M-XPort	TAPE 5	5	SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
NETWORK	Network	BLUETOOTH 9	9	TUNE –	I<<Tune-	PRESET-	I<< / Preset-
INTERNET RADIO	Internet Radio	LIST SMART	Smart / List	TUNE –	I<<Tune-	TUNE-	<< / Tune-
CH / PAGE	CH+	CH + PAGE	CH+ / Page+		Play / Pause	SLOW	Play / Slow

Original		Replacement		Original	Replacement
►/II	Play / Pause	STEP-FREEZE II	Pause / Step / Freeze		
TUNE+ ►►I	>>I / Tune+	TUNE+ ►►	>> / Tune+		
TUNE+ ►►I	>>I / Tune+	PRESET+ ►►I	>>I / Preset+		
1	Favorite Station	TITLE SOUND	Sound / Title		
2	Favorite Station	LANG I/II AUDIO	Audio / Lang I/II		
3	Favorite Station	EQ SUBTITLE	Subtitle / EQ		
MOVIE	Red/Movie	NETFLIX SEARCH	Red / Netflix / Search		
MUSIC	Green/Music	APP REPEAT	Green / APP / Repeat		
GAME	Blue/Game	Prime Video RANDOM	Blue / Prime Video / Random		
PURE	Yellow/Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat		

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ON/STANDBY	On/Standby		Power
CBL/SAT	CBL/SAT	HDMI - SAT 0	0
DVD	DVD	DVD 2	2
Blu-ray	Blu-ray	VIDEO 4	4
GAME	Game	PC FAV MARKER	Fav / Marker / PC
AUX	AUX	AUX - HDD 7	7
MEDIA PLAYER	Media Player	MEDIA DISPLAY	Display / Media
TV AUDIO	TV Audio	TV 1	1
CD	CD	CD - STB 3	3
TUNER	Tuner	TUNER 6	6
iPod /USB	iPod/USB	USB 8	8
PHONO	Phono	-/-- GUIDE EPG	Guide / EPG / -/--
M-XPort	M-XPort	TAPE 5	5
NETWORK	Network	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	LIST SMART	Smart / List
CH / PAGE	CH+	+ CH PAGE	CH+ / Page+

Original		Replacement	
VOLUME	Vol +	+ VOL	Vol +
CH / PAGE	CH-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Vol -	VOL –	Vol -
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
OPTION	Option	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<<Tune-	PRESET-	I<< / Preset-
TUNE –	I<<Tune-	TUNE-	<< / Tune-
▶/II	Play / Pause	SLOW ▶	Play / Slow
▶/II	Play / Pause	STEP - FREEZE II	Pause / Step / Freeze
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+

Original		Replacement		Original	Replacement
TUNE+	>>I / Tune+	TUNE+	>> / Tune+		
1	Favorite Station	TITLE SOUND	Sound / Title		
2	Favorite Station	LANG I/II AUDIO	Audio / Lang I/II		
3	Favorite Station	EQ SUBTITLE	Subtitle / EQ		