Original		Replacement	
POWER	Power		Power
DIMMER	Dimmer	APP MEDIA	Media
CLOCK	Clock	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
INTERNET RADIO	Internet Radio	SEARCH TV/R	TV/R
USB	USB	PICTURE FORMAT	Format
MUSIC SERVER	Music Server	A	Red
TUNER	Tuner	B	Green
ANALOG IN	Analog In	C	Yellow
OPTICAL IN	Optical In	D	Blue
Bluetooth	Bluetooth	HOME SMART	Smart
CD	CD	FAV PRE-CH	Pre Ch
CH +	>>I / CH+	>>I	>>I
CH –	I<< / CH-	I<<	I<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
■	Stop	■	Stop

Original		Replacement	
TUNE +	>>/ Tune+	>>	>>
TUNE –	<</ Tune-	<<	<<
ADD FAVORITES	Favorites ADD	+ CH	Ch +
FAVORITES CALL	Favorites Call	CH –	Ch -
SDB TONE	SDB Tone	E-MANUAL D.MENU	D. Menu
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
QUEUE	Queue	AD SUBT	Subt
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
▲	Up	▲	Up
▼	Down	▼	Down
►	Right	►	Right
◄	Left	◄	Left
ENTER	Enter	OK	Ok

Original		Replacement	
1	1	1	1
2 ABC	2	2	2
3 DEF	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
6 MNO	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
9 WXYZ	9	9	9
0	0	0	0
+10	+10	GUIDE	Gui de
CLEAR	Cl ear	EXIT	Exi t
RANDOM	Random	DUAL	Dual
REPEAT	Repeat	TEXT	Text
PROGRAM MODE	Mode/ Pr ogr am	3D	3D
INFO	I nf o	INFO	I nf o

Original	Replacement