Original		Replacement	
POWER	Power		Power
RECORD	Record	REC MODE	Rec / Rec Mode
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
INFO	Info	ANGLE INFO	Info / Angle
0	0	HDMI-SAT 0	0
RECALL	Recall	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
PLAY	Play	SLOW	Play / Slow
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
STOP	Stop	HOLD	Stop / Hold
CH+	Up/CH+		Up
VOL-	Left		Left
VOL-	Vol -	VOL	Vol -
OK	OK	OK	OK
VOL-	Right		Right
VOL-	Vol +	VOL	Vol +
CH-	Down/CH-		Down
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze

Original		Replacement		Original	Replacement
TTX	TTX	GOTO TEXT	Text / Goto		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /		