Original		Replacement	
MODE	Mode		Power
EPG OSD	EPG/OSD	-/-- GUIDE EPG	Guide / EPG / -/--
TV/MUSIC REPEAT	Tv/Musci/Repea	PROGRAM TV/RADIO	TV/Radio /
PIC	PIC	FORMAT PICTURE	Picture / Format
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
FAVORITE PR TITLE	Title/Favorite P	TITLE SOUND	Sound / Title
MEMORY MENU	Menu/Memory	HOME MENU	Menu / Home
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement	
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
EXIT ZOOM	Zoom/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏮	I<<	SHIFT + PRESET- ⏮	Shift + I<< / Preset-
⏭	>>I	SHIFT + PRESET+ ⏭	Shift + >>I / Preset+
⏭	>>I	PRESET+ ⏭	>>I / Preset+
CH-	CH-	CH PAGE −	CH- / Page-
CH-	<<	SHIFT + TUNE- ◀◀	Shift + << /
CH-	<<	TUNE- ◀◀	<< / Tune-
CH+	CH+	+ CH PAGE	CH+ / Page+
CH+	>>	SHIFT + TUNE+ ▶▶	Shift + >> /
CH+	>>	TUNE+ ▶▶	>> / Tune+
ENTER	Enter	OK	OK
TELETEXT ANGLE	Angle/Teletext	GOTO TEXT	Text / Goto
GUIDE SLOW	Slow/Guide	SHIFT + SLOW ▶	Shift + Play /
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original	Replacement
Play/Pause	Play / Slow
Stop/PR List	Stop / Hold
PG Up/Info	Up
PG DN/Sleep	Down

Original	Replacement