Original	Replacement	Original	Replacement
Power	Power	Menu	Menu / Home
Open / Close	Eject / Surround	Setup	Setup / OPT /
P/N	Smart / List	Up	Up
Prog	TV/Radio /	Left	Left
Mark	Fav / Marker / PC	Enter	OK
1	1	Right	Right
2	2	Down	Down
3	3	Title	Sound / Title
4	4	OSD	Display / Media
5	5	Step	Pause / Step / Freeze
6	6	Stop	Stop / Hold
7	7	Play/Pause	Play / Slow
8	8	Vol +	Vol +
9	9	FB	<< / Tune-
0	0	FF	>> / Tune+
10+	Guide / EPG / -/--	Vol -	Vol -
Clear	Exit / Cancel / Clear	Prev	I << / Preset-

Original	Replacement	Original	Replacement
Next	>>I / Preset+		
Mute	Mute / Dimmer		
Audio	Audio / Lang I/II		
Sub-T	Subtitle / EQ		
Zoom	Zoom / Size		
Goto	Text / Goto		
Angle	Info / Angle		
Repeat	Green / APP / Repeat		
A-B	Yellow / YouTube / Repeat		
Slow	Shift + Play /		
Video	Shift + 4		
V-Remote	D. Menu / Top		
Default	Picture / Format		